



## Quick Installation Guide

# 802.11g Wireless Music Bridge

Model # AWMB100



Ver. 1A

# Section 1

*This Quick Installation Guide only provides basic instructions. For detailed information on using this product, please refer to the User's Manual on the supplied CD.*

## Installing Software


**Note:** The setup should be done from the computer you want to use with the music bridge.

**Step 1** Insert the Utility CD into your CD-ROM drive. When the autorun screen appears, select **Install Utility and Driver** from the menu.




**Note:** If the autorun window does not appear automatically, go to Start -> Run and type **D:\Utility\Setup.exe** (where **D** is the letter of your CD-ROM drive) and click **OK**.

**Step 2** Click **Next** at the welcome screen.



**Step 3** Click **Install** at the installation screen.




## Section 2

### Running Setup Wizard

**Step 1** After the software installation finished, the setup wizard will automatically appear. Click on the **Click Here to Start**.




If the wizard does not come up, you can go to **Start > All Programs > Airlink101 Wireless Music Bridge > AWMB100 Setup Wizard**.




**Step 2** Power on the Wireless Music Bridge. Click **Next**.




**Step 3** Connect one end of a networking cable to the computer you plan to use with the music bridge, then connect the other end to the Ethernet port on the back of the music bridge. Click **Next**.



**Step 4** Verify if the LEDs LAN and Power are on. Click **Next**.



**Step 5** A list will appear showing your Music Bridge. Select it from the list and click **Next**. If nothing appears on the list, make sure that the music bridge is connected to your computer and properly powered on. Also make sure that you disable any software firewalls you have installed on your computer.



**Step 6** The default username for the music bridge is **admin** and the default password is **admin**. Enter this into the appropriate boxes and click **Enter**.

AirLink 101 Wireless Music Bridge - 1.00.05

**2 Password**

Please Input Wireless Music Bridge's Password

Input User Name and Password

User Name:

Password:

The default User Name and Password are both "admin".

Back Enter

**Step 7** This screen allows you to change the **device name**, **username**, and **password**. If you want to change any of this information, enter it into the boxes and click **Next**. You can also leave the default settings and click **Next**.

AirLink 101 Wireless Music Bridge - 1.00.05

**3 Change Password**

Change Wireless Music Bridge's Password

Input Password

Device Name:

User Name:


Create a password and enter it in the new password field. Re-enter the password in the confirm field.

New Password:


Confirm:

Back Next

**Step 8** If you are not using the wireless function of the music bridge, click on **I only have a wired network** and the configuration is complete. You can now connect the music bridge to your router and start playing music. If you plan to use the music bridge wirelessly, go to **Step 9**.



**Step 9** Select your network from the list and click connect.



**Step 10** If your network is encrypted, enter the encryption information at the next screen and click **Next**.



A screenshot of a web browser window showing the setup interface for an Airtelink 101 Wireless Music Bridge. The browser title is "Airtelink101 Wireless Music Bridge - 1.00.05". The page header includes the Airtelink 101 logo and the text "AWMB100 802.11g Wireless Music Bridge". The main heading is "Encryption Key". Below it is a blue bar labeled "Manual Setup". The setup area contains the following information: "Wireless Network" set to "default", "Encryption Type" set to "WPA-PSK (TKIP)", and two empty text input fields labeled "Input" and "Confirm". Below these fields is a note: "Limit note: 8-63 characters". At the bottom of the page are two buttons: "Back" and "Next".

**Step 11** The setup is complete. Click on **Finish** to save the settings.



A screenshot of the same web browser window showing the "Setup Complete" screen. The browser title remains "Airtelink101 Wireless Music Bridge - 1.00.05". The page header is the same. The main heading is "Setup Complete". Below it is a blue bar with the text "The Wireless Music Bridge has been successfully configured". To the left is an image of the Airtelink 101 Wireless Music Bridge device. To the right of the image is the text "Congratulations!". Below that is a note: "Please click 'Finish' to apply the current settings." At the bottom of the page is a single button labeled "Finish".

**Step 12** You can now disconnect the music bridge from your computer and connect it to your stereo system. The following is a description of the different audio outputs on the Music Bridge.



**Green** – Headphones/Stereo/Front Surround – **Plug in your stereo speakers or headphones here.** If you are setting up surround sound, use this connection for your front surround speakers.

**Orange** – Center channel/Subwoofer – This connection is used for surround sound. Connect your center channel and subwoofer to this output.

**Black** – Rear Surround – This connection is used for surround sound. Connect your rear surround speakers to this connection.

**Optical Out – S/PDIF Out** – This is an optical digital output for connecting to an external receiver.

## Section 3


### Connecting to the Music Bridge

**Step 1** Double click on the Wireless Audio Center icon in the system tray.




If the icon does not appear in the system tray, you can go to **Start > All Programs > Airlink101 Wireless Music Bridge > AWMB100 Audio Center.**


**Step 2** Click the **Scan Audio Device** button. The software will search for and find all Music Bridges on the network.



**Step 3** Select the music bridge you wish to use from the list and click the **Connect** button.



**Step 4** Choose the appropriate **Playback Buffer Mode** for the type of audio you are playing and click **Confirm**.



You can now play audio on your computer and it will be sent to the music bridge.

## Section 4

### Technical Support

E-mail: [support@airlink101.com](mailto:support@airlink101.com)

Toll Free: 1-888-746-3238

Website: [www.airlink101.com](http://www.airlink101.com)

\* Theoretical maximum wireless signal rate based on IEEE standard 802.11g specifications. Actual data throughput will vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, mix of wireless products used, radio frequency interference (e.g., cordless telephones and microwaves) as well as network overhead lower actual data throughput rate. Specifications are subject to change without notice. All products and trademarks are the property of their respective owners. Copyright ©2007 Airlink101®